


Slant/Fin. Fast/Flex. Bronze Connectors









INSTALLATION INSTRUCTIONS: Clean fittings before soldering. Use non-acid (rosin) flux. Install Fast/Flex so that expansion or vibration movement will be at right angles to the flex section, and will not subject it to "accordion action." Avoid outside abrasion of the flex section. Do not twist hose when tightening threaded fittings.

WORKING PRESSURES: Maximum working pressure, 150 PSI, up to 300°F. on all items up to 1½" diameter; for larger sizes, 75 PSI where both ends are anchored and cannot elongate; otherwise 30 PSI. (Bursting pressures are much higher, but slight elongation of hose may occur at higher pressures.)

The complete Slant/Fin line includes baseboard and commercial fin-tube radiation, radiant heating, boilers, and hydronic accessories; information on request.



©Slant/Fin Corp. 2011. Printed in the U.S.A. 111. Publication No. EC-FF-10.

U.S.A. Slant/Fin Corporation • 100 Forest Drive Greenvale, NY 11548 • 516-484-2600 www.slantfin.com

Slant/Fin LTD/LTEE • 6450 Northam Drive Mississauga, Ontario L4V 1H9 • 905-677-8400 www.slantfin.ca